




Security Management Australasia

Video Entry Panels

PUSHBUTTONS AND THEIR FUNCTIONS

To call an APARTMENT from the main entry door stations

1. Dial the Apartment number with the KEYPAD and then press the call button 



Example

To call apartment 103. Press button 1 then 0 then 3 followed by the call button

You will hear the call ring the apartment, please wait for the call to be answered


OR

2. Press the up and down buttons until the apartment number appears on the DISPLAY SCREEN


Example  and then press the call button 

You will hear the call ring the apartment, please wait for the call to be answered

If you make a mistake wait for 30 seconds for the system to re-set itself and start again



Video Handset Instructions



1. When a call is received from any of the main door stations the handset will ring once and the video screen will turn on for approximately 50 seconds.
2. To talk to the caller, lift the handset.

3. To allow entry through the door press the **door unlock button**.



4. To allow the Lift to access your level, press the **Lift Call button**.



5. To View the door station camera press the **Monitor on button**. The video screen will turn on for approximately 50 seconds.



6. The ring volume can be set to high, medium or low by sliding the **Bell Volume Adjuster** left or right.

7. The buttons behind the flap can adjust the video image contrast and brightness.

Should you experience any problems,
please contact
The Building Manager